

1 Comp. Loc. Camera

◆ ⇒ "1.1 Peripheral Camera", page 1

◆ ⇒ "1.2 Rear View Camera", page 1

1.1 Peripheral Camera

2 - Right peripheral camera -R245-

2 - Left peripheral camera -R244-

4 - Peripheral camera control module -J928


□ located under the front seat

5 - Rear peripheral camera -R246-

□ Inside the rear lid handle. It is permanently attached to the button.


7 - Front peripheral camera -R243-

Protected by copyright. Copying for private or commercial purposes, in whole or in part, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee the accuracy of the information with respect to the correctness of information in this document. Copyright © 2015 Audi AG



1.2 Rear View Camera

- 1 - Rearview camera system control module -J772
 - ❑ located behind the right luggage compartment trim panel.
- 5 - Rearview camera -R189-
 - ❑ located inside the handle assembly



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.